

Firmware-Update HM8118

Dear valued Customer,

Our goal is to improve our products continuously.
You are invited to download the most recent
firmware under <http://www.hameg.com>.

Firmware Update

For the firmware update, the software framework
.net 2.0 is required. Normally, this framework is
included in WinXP SP2. For other versions of
Windows, please refer to the Microsoft website:

<http://www.microsoft.com/downloads/de-de/details.aspx?displaylang=de&FamilyID=0856eacb-4362-4b0d-8edd-aab15c5e04f5>

You can update the firmware via physical COM
port. By using a USB-RS-232 adapter timing
problems can occur. We recommend the
connection via serial interface cable (1:1 wired).

Please notice that the firmware update can not
start from network drive. You can only start the
firmware update from a local hard drive.


Execution of the firmware update

Please extract the ZIP file in a folder of your hard
drive.

Connect the HM8118 via serial interface RS-232
with your PC (RS-232 cable 1:1 wired) and start
the file **Flash_8118_V_x_x.exe**.


Select the appropriate COM port.

Press „**Start**“ to set the HM8118 in boot-mode.
Wait until the HM8118 display is erased.




Press „**Program**“ until the old sections of the
HM8118 are cleared.

Select the file "**HM8118-Vxxx-S0.hex**" manually.



The update starts automatically beginning with
sector 0 up to sector 7. The programming
procedure will take about 12-15min.



When the update is completed successfully, the
HM8118 performs a reset automatically. In case a
checksum error is displayed, please try to update
the firmware again.

